


Ersatzteile / Spare parts Linienlaser / Line Laser FL 40-Classic (511000)



Nr.	Description	St. / Qty.	EUR pc./St.	total/Gesamt
1	Mark plate (big)		0,50	
2	Mark plate (small)		0,50	
3	Screw		0,30	
4	Top cover		2,00	
5	Button		0,50	
6	Spring		0,40	
7	Battery cover		1,50	
8	Shell		6,00	
9	Electronic controlled plate-1		4,00	
10	Screw		0,40	
11	Metallic wire		0,65	
12	Screw		0,30	
13	Electronic controlled plate-2		2,00	
14	Laser assy.		85,00	
15	Oil-cup assy.		14,00	
16	Block plate		1,00	
17	Hinged assy.		22,75	
18	Window cover		4,35	
19	Screw		0,30	
20	Wall-bracket (w/o picture)		9,50	
21	Bag (w/o picture)		9,20	
22	Compensator clamp		2,50	